

ins

ins

**A**

1  
Open slot

2  
Open slots

3

4

5

Graf Zeppelin  
LZ 127

Graf Zeppelin  
LZ 127

6

7

8  
Open slot

9

10

11

12  
Open holes  
(2 places)

13

14

15


16

17

18

**A**

cm




B

B

**C**



1



2




3




4


5




6




7



8




e




9

10




11




d

e




14




f

13




f

12




d

16




g

15




g


19



21



20



22

grafzep\_parts.pdf v1.0  
©2008 by Ralph Currell

**C**